Contactless Twins Charger for Wii Remote Control

Wi08

User's Manual

PRODUCT FEATURES

- Simply charge your Wii remote control without tacking off the silicon jacket and battery.
- Allow you to charge two Wii remote controls at the same time.
- Leading technology of wireless power transfer

CONTENTS

Contactless power charger stand x 1

Remote control battery module x 2

AC adapter x 1

RFID
POWER
CONTACTLESS CHARGER
Contactless Twins Charger for Wii Remote Control
Wi08
User's Manual
PRODUCT FEATURES
Simply charge your Wii remote control without tacking off the silicon jacket and battery.
Allow you to charge two Wii remote controls at the same time.
Leading technology of wireless power transfer

User's manual x 1

USAGE INSTRUCTION

1.

Connect the adapter to the AC plug.

2.

Connect the adapter cable to the charger stand jack.

3.

Put the battery into the Wi08 remote control battery module and install it.

4

Gently put the remote control on the power charger stand and check the LED indication to ensure the charging start.

* The hole in the Wi08 battery cover is reserved for the sync button.

LED Indication



Green ON	Charging Finished
Green Blink	Charging
RED ON	No Charging
RED Blink	Error

SPECIFICATION

Input	DC 6V/1A
Radio Frequency	250KHz
AC Adapter	100-240V/50-60MHz
Power Consumption	Stand-by Mode: 1W Charging mode: 5W
Battery	AAA 1.2V 800mA
Charge Time*	About 3 Hours
Charge Control System	Peak-cut System
Simultaneous Charging Units	2
Operating Temperature	0~55° C
Operating Humidity Range	20%~80%
Dimension	Contactless Power Charger:149 x 95 x 78(mm) Battery Charger Module: 36 x 86 x 14(mm) AC Adapter: 58 x 31x 51(mm)
Certifications	CE, FCC, VCCI

* Charge time varies in different environment and battery conditions

NOTE

For your own safety and to avoid damaging the product, please follow below instructions:

1 Make sure that you have changed to the re-chargeable batteries before use.
2 Make sure that you have changed to the enclosed battery cover before use.
3 Whenever using the product, do not let it come in contact with any liquid.
4 Do not disassemble or damage the product in any way.
5 Keep it away from any metal objects.

WARMING

1 Keep the product out of direct sun light and away from heat and fire.
2 For use by children age 12 or above and then only under the supervision of an adult.
3 This product can only be used with the enclosed battery cover and re-chargeable batteries.
4 Please take note of the indicator light signal, especially if the red light is flashing which means error, please stop using immediately and check the instructions in the owner's manual.

Warranty

Model No.	
Purchaser	
Date of Purchase	
Telephone	
Address	
Retailer	

Warranty

- The warranty proves that this product is produced through highly quality control, and provides 1-year warranty since selling data when it is used in normal situation.
- The sheet information should be written down exactly and this warranty will be executive with the signature of the retail shop
- Please do have this warranty in repairing
- Please do well-keep this warranty, We don't give any other warranty when this warranty is lost.
- We free repair product in warrant when it is used in normal situation.
- We will free repair for charge in the following situation when there are any problems:

1. There are damages due to external causes, including accident, problems with electrical power, usage not in accordance with product instructions, neglect, alteration, repair, improper installation or improper testing.
2. Do not have this warranty in repairing
3. Do not correctly register data, or data is corrected